



Congratulations! You have a Switch. The kite that makes no sense.

First Quick Start :




Pull the Switch from its pouch and run it into the air. The Switch should open by itself. Otherwise one can shake. Attach your line (Dyneema 90kg recommended 40m) to the mobile flange "shuttle" for a lark's head knot Run it in the air and fly !

Use

Using the Switch with 10 to 20 m line for a small or light winds 20 to 40m and an average Each jerk on the line tilts the shuttle and changes the direction of flight. This is the "switch" With a soft or fixed to the ground control is a stable kite single line. With a control based on pulses and detents the line, this is a complete stunt kite. Flip, switch, yoyo, axel fade and are all currently listed figures. The adjustable straps on the left and right to enlarge or flatten the Switch. Next if the wind is strong or weak and the desired sensation.

Folding

- 1 : Hold Switch left and right. On the one hand, do dive in the middle of the kite. The Switch is deformed and EVERY wings form a 8
- 2 : Close the other side on top. 8 make a circle .



Switch

Static flight

Acrobatic flight

Bit	1	2	3	4	5
Km/h	1 à 5	6 à 11	12 à 19	20 à 28	29 à 38

Video of storage



Règles de sécurité élémentaires pour la pratique du cerf-volant
- Faire preuve de bon sens quelle que soit l'occasion -



Interdiction de voler à proximité des lignes électriques, téléphoniques, Antennes etc. Le fil d'un cerf-volant se charge en humidité et devient conducteur électrique.



Ne pas voler par temps d'orage. Le fil d'un cerf-volant se charge en humidité et devient conducteur électrique.



Interdiction de voler à Proximité des aéroports, aérodromes, hélicopters et dans un rayon de 10 Km. Au delà de cette limite, la hauteur de vol maximal légale est de 100 mètres.



Ne pas voler près des habitations, des routes et des zones boisées. Le vent y est mauvais et instable, les cerfs-volants s'accrochent facilement aux obstacles. Un lieu bien dégagé est recommandé.



Ne pas voler au dessus du public. En chutant, un cerf-volant et ses lignes peuvent provoquer des blessures graves.

www.alain-micquiaux.fr 2015

The Switch is not a toy suitable for a child under 14 years of age.
-Made in France-



Création Alain MICQUIAUX
www.alain-micquiaux.fr

Video also available on the website :
<http://www.alain-micquiaux.fr/shop/switch/>